

SMART actuators with sensing ability based on Heusler microwires.

L. Nulandaya^{1,2}, L.Frolova², M. Hennel², T. Ryba³, O. Milkovic¹,
O. Heczko⁴, R.Varga^{1,3}



RVmagnetics


When size matters

¹IEP, Slovak Academy of Sciences, 040 01 Kosice, Slovakia

² CPM-TIP, UPJS, Tr. SNP 1, 040 01 Kosice, Slovakia

³ RVmagnetics, Nemcovej 30, 040 01 Kosice, Slovakia

⁴IoP, CAS, Na Slovance 2, 18221 Prague, Czech Republic



CPM TIP, UPJS

Advantages of wire shape actuators

(motivation)

Shape anisotropy

Enhancement of functionality in a single direction


Straining in a single direction

Surface / Volume fraction

Low eddy current

Simple production of large amount


Simple processing in applications



Heusler microwires for shape memory applications

The biggest problem is Mn

Novel composition $\text{Ni}_{50}\text{Fe}_{25}\text{Ga}_{25}$



APPLIED PHYSICS LETTERS
VOLUME 82, NUMBER 3
20 JANUARY 2003

Martensitic transformation and shape memory effect in ferromagnetic Heusler alloy Ni_2FeGa

Z. H. Liu, M. Zhang, Y. T. Cui, Y. Q. Zhou, W. H. Wang, and G. H. Wu^{a)}
State Key Laboratory for Magnetism, Institute of Physics, Chinese Academy of Sciences, Beijing 100080, People's Republic of China

X. X. Zhang
Department of Physics, The Hong Kong University of Science and Technology, Clear Water Bay, Kowloon, Hong Kong, People's Republic of China

Gang Xiao
Department of Physics, Brown University, Providence, Rhode Island 02912


(Received 3 September 2002; accepted 11 November 2002)

We have synthesized ferromagnetic Heusler alloy Ni_2FeGa using the melt-spinning technique. The Ni_2FeGa ribbon, having a high chemical ordering $\text{L}2_1$ structure, exhibits a thermelastic martensitic transformation from cubic to orthorhombic structure at 142 K and a premartensitic transformation. The alloy has a relatively high Curie temperature of 430 K, a magnetization of 73 Am⁻¹/kg, and a low saturated field of 0.6 T. The textured samples with preferentially oriented grains show a completely recoverable two-way shape memory effect with a strain of 0.3% upon the thermelastic martensitic transformation. © 2003 American Institute of Physics. [DOI: 10.1063/1.1534612]

Energy Dispersive X-ray
(EDX) analysis:
 $\text{Ni}_{50.03}\text{Fe}_{25.36}\text{Ga}_{24.61}$ (at.%)

SEM HV: 20.0 kV	WD: 11.29 mm	VEGA3 TESCAN
View field: 1.17 mm	Det: SE	200 μm
SEM MAG: 186 x	Date(m/d/y):	10/21/16

Heusler microwires for shape memory applications



High temperature Austenite



$$a=5.756 \text{ \AA}$$

Phase transition between
240-290 K

Low temperature- monoclinic
 $a=4.1593 \text{ \AA}$, $b=5.3767 \text{ \AA}$, $c=20.7616 \text{ \AA}$
 $\beta=86.734^\circ$

Heusler microwires for shape memory applications

$\text{Ni}_{50}\text{Fe}_{25}\text{Ga}_{25}$
Monocrystalline structure !!!




**Strong stresses due to glass
can be released by
orientation of crystal lattice**

$<111>$ direction // wire's axis

Heusler microwires for shape memory applications

$\text{Ni}_{50}\text{Fe}_{25}\text{Ga}_{25}$



Dynamic Mechanical Analyzer (DMA)
analysis

**Reversible Phase transition
Maximum strain 2%**

**But also 1200 % variation
of permeability**

SMART actuator

Heusler microwires for shape memory applications





Using Giant Magnetolmpedance (GMI) for sensing


Easy axis change =>
permeability change =>

GMI change

Smaller variation of GMI,
but clearly recognized and
easier for applications



Heusler microwires for shape memory applications



Stress application =>

Reversible Phase transition
Maximum strain over 4%



Adjustment of
Transformation temperature

260MPa($\Phi \sim 100\mu\text{m}$) $\sim 800\text{g}$

Heusler microwires for shape memory/magnetocaloric applications




Phase transition temperature depends on e/a




Heusler microwires for shape memory

$\text{Ni}_{50}\text{Fe}_{27}\text{Ga}_{23}$

Transition $\sim 320\text{-}380\text{K}$




Monocrystalline



Heusler microwires for shape memory

$\text{Ni}_{50}\text{Fe}_{27}\text{Ga}_{23}$

Heated by el. current




Repetitive cycling
over 1 000 000 times

at 1Hz

$i_{AC} \sim 30\text{mA}$


Strain >20%



Summary

Ni-Fe-Ga based microwires for shape memory applications:


- Small dimensions
- Easy production process
- Must be repeatable
- Adjustable T_m
- Monocrystalline structure helps
- Duration over 1 000 000 cycles
- 100 μ m can lift up to 800g
- Smart actuators



FUTURE

Artificial SMART muscles

Can sense its actuation through the permeability or Impedance sensing =>
Very precise control of motion



Contactless pump/syringe (in-vivo?)





RVmagnetics

Thank you for your attention

When size matters

Development of miniaturized smart sensors